




Body Coupled Communication

Presentation By:
Adam Barth...Again






Types of Communication

- Optical/Infrared
 - Requires line of sight
 - Omni-directional devices can consume a lot of power
- Far-field (RF)
 - Omni-directional (good/bad?)
 - Received power reduces by $1/r^2$
 - Eavesdropping?
 - Off-body communication?
- Near-field (magnetic/electrostatic)
 - Normally not omni-directional
 - Received power reduces by $1/r^3$
 - Privacy?
 - Distance limitations?




What is BodyComm

- Can be considered near-field or somewhere in between
- Uses the human body as a transmission medium
 - Health concerns?
- Generally limits communication to items in contact to the body
- Normally operates at low frequencies
 - Body absorption




Types of BodyComm



- Which is best for BANs?
 - External dependence
 - System complexity
 - Wearability
- How do they compare to RF communication?

Electrostatic BodyComm



- Zimmerman (1996) MIT and IBM
- Electrostatic coupling
- Relies on small capacitive coupling to common “earth” ground






Electrostatic Models

- Electrostatic circuit with external ground reference
 - What capacitances are assumed?
 - How can they vary?






Electrostatic BodyComm


- Practicality:
 - Somewhere with strong “ground” capacitance is recommended
 - Shoe computer?
 - Commercial systems are available
 - [RedTacton](#)
- Would this work for BAN application?
 - Entertainment/Gaming
 - Medical



Waveguide BodyComm



- Uses the body as a waveguide for EM waves
- Little to no dependence on external environment
- Uses two transducers at each site





Waveguide BodyComm Research

- Keisuke Hachisuka (University of Tokyo)
- Experiments using Ag-Cl electrodes
 - Frequency characteristics
 - Electrode pair patterns
 - Electrode compositions
 - Electrode placement on body




Frequency Experiments


- Electrodes on a forearm
- Frequency sweep from 1-50 MHz
- Shown to be better than airborne propagation
 - Problems?
 - Ambiguities?



Frequency Results




Hachisuka (Sensors and Actuators, February 2003)




Hachisuka (the 12th International Conference on Solid State Sensors, Actuators and Microsystems, June 2003)

Our Frequency Tests

- 5 test subjects (Harry, Dincer, Mark, Me, and two females 20-23 years of age)
- Two carbon conductor electrodes on each wrist
 - One set connected to RF function generator (-12dBm TX power)
 - One set connected to spectrum analyzer
- Frequencies swept from 1-50 MHz



Our Frequency Results





Our Frequency Results

- What do these results show?
 - Relative consistency across subjects
 - Common resonant frequencies
 - Excellent receive strengths!!
 - Even without matching impedance to body



Waveguide Frequency Tests

- Problems with tests?
 - Common ground plane
 - Electrodes
 - Feasibility
 - Unknown frequency characteristics
 - Availability of small, low-power transceivers at the frequencies tested
- Other tests are needed
 - Some have already been done

Electrode Pair Pattern Tests






Fig. 6. Differences in propagation gain for three patterns of electrodes.





Electrode Impedance Tests







Electrode placement Tests



Comparison to 2.4 GHz

- 13.56 and 23 MHz carriers were selected for comparison
- Conducted tests with various positions on the body of subject 1



13 to 34 dB improvement over 2.4 GHz (between 20X and 2500X better)



Comparison to 2.4 GHz

- What do we gain with BodyComm?
- FSK Equations:


$$P_p = 1 - (1 - P_e)^N \quad (1)$$

$$P_e = \frac{1}{2} e^{-\frac{E_b}{2 \cdot N_0}} = \frac{1}{2} e^{-\frac{P_r}{2 \cdot N_0 \cdot R_b}} \quad (2)$$

- ZigBee boasts 1% PER, 1000bits/packet, and 250kbps throughput at -92 dBm RX power
- With reasonable assumptions for N_0 and T_{sys} , we could transmit at around -52 dBm and see the same results

BodyComm Prototype

- Analog FM transmission at 10.7 MHz
- Assembled from all COTS components at low cost





BodyComm Theory

- What is actually going on with waveguide BodyComm?
 - $\frac{1}{4}$ wave length at 10.7 MHz is 28 meters
- How much radiation is there away from the body?
- What accounts for small variations among test subjects?
- What can we gain from knowing all of this?




BodyComm Theory

- One way to answer some the aforementioned questions is by constructing a model of the human body's impedance (bio-impedance analysis)
- Most research in this area is somewhat proprietary
 - Consumer scales that give body fat, etc.
- A simple model can be constructed using HFSS
 - 3 cylinders (two arms and one body), with input and output ports on the right and left arms
 - 0.2 Siemens/m was used for the conductivity
 - 70 was used for the relative permittivity constant




HFSS simulation



The magnitudes of the E-field inside the body

HFSS Simulation



The magnitudes of the E-field inside the body and the air around the input arm



HFSS Simulation

Frequency	Impedance Real and Imaginary			
	13.56 MHz		23 MHz	
	<i>Left Wrist</i>	<i>Right Wrist</i>	<i>Left Wrist</i>	<i>Right Wrist</i>
<i>Left Wrist</i>	$0.982 + j162$	$1.797\text{E-}5 - j463$	$0.948 + j149$	$4.934\text{E-}5 + j96.2$
<i>Right Wrist</i>	$1.799\text{E-}5 - j463$	$0.983 + j163$	$4.934\text{E-}5 + j96.2$	$0.951 + j151$

Table 1. HFSS Impedance results.

Frequency	E-Field Magnitude			
	13.56 MHz		23 MHz	
	<i>Left Wrist</i>	<i>Right Wrist</i>	<i>Left Wrist</i>	<i>Right Wrist</i>
<i>Left Wrist</i>	0.98139	1.80E-05	0.94796	4.93E-05
<i>Right Wrist</i>	1.80E-05	0.98256	4.93E-05	0.95124

Table 2. HFSS E-Field Magnitude simulation results.




Ideas for More Experiments

- HFSS has a human model built for use in MRIs
 - Using this could get much more accurate simulation results
- Decouple from common ground plane and repeat receive strength measurements
- Use an anechoic chamber to measure radiated energy
- See if it can be capacitively coupled to the skin

BodyComm Privacy

- What are the implication of a “body-contained” network
 - Malicious attacks are limited to very close proximity
 - Facilitates spatial reuse
 - Reduces interference in dense environments

RF Radiation



BodyComm
“bubbles”



BodyComm Applications

- What applications could benefit from BodyComm?
- What applications should remain RF?
- Is there enough demand for a BodyComm bote?



BodyComm Implications

- Should this still be considered a BAN?
 - What is the difference between BSNs, BANs, and PANs
- What will BodyComm do to processor power requirements?

● ● ● | Questions?

